

Specialist Construction Supplies for Repair, Maintenance, Building & Infrastructure

Ultra DPM IT A Data Sheet

Specification notes

Product: Ultra DPM IT A

Supplier:

Arcon Construction Supplies 19-20 Prestwood Court Leacroft Road Warrington WA3 6SB

Tel: 01925 852225

Email:<u>mail@arconsupplies.co.uk</u>
Web: <u>www.arconsupplies.co.uk</u>

Call 01925 852225 or visit Arcon Construction Supplies

... for more information on our flooring and construction products



Technical Data Sheet

Fast Curing Additive

Features

- Reduces curing times
- Allows fast installation of floor coverings
- Compatible with DPM IT one coat and DPM IT two coat

DPM IT A is a damp proof membrane additive, specifically designed for DPM IT one coat and DPM IT two coat. It reduces the products' curing times to as little as 3 hours after application.



30 min Pot Life



3 hours Open Time



Internal Floors



Lifetime Guarantee















Fast Curing Additive

INFORMATION

DPM IT A is a damp proof membrane additive, specifically designed for use with DPM IT one coat and DPM IT two coat damp proof membranes. The product reduces their curing times to as little as 3 hours after application and allows for the early installation of vinyls, carpets and other resin-based products in fast track building programs.

SURFACE PREPARATION

Please refer to individual Technical datasheets for more information.

MIXING

Drain contents of hardener bottle into the base resin container and mix thoroughly for a minimum of 2 minutes with a power whisk fitted in a low speed electric drill. Mix until a homogeneous mix and a uniform colour is obtained. Pay special attention to scrape sides and base of container. Then add the entire contents of the DPM IT A tin and mix for a further 1 minute. **Note:** Use only one unit of DPM IT A per 10kg DPM IT one coat or DPM IT two coat damp proof membranes.

APPLICATION TECHNIQUES

Please refer to individual Technical datasheets for more information. **Note:** It is essential that the product be applied immediately after mixing. DPM IT A is extremely fast curing and failure to use the mixture at once may result in the product curing in the bucket.

CURING

When DPM IT A combined with DPM IT one coat and DPM IT two coat is used, the curing time of these products will be reduced to approximately 3 hours at 20°C.

TECHNICAL DATA	
Packaging:	500ml Metal tin.
Mixing Ratios:	1 unit of product to 10kg DPM IT one coat or DPM IT two coat damp proof membranes.
Cure Schedules:	Approximately 3 hours at 20°C when mixed with a DPM IT damp proof membranes.
Storage:	Store in sealed original containers at temperatures between 5°C and 25°C. Store in a cool and well-ventilated place.
Shelf Life:	12 months in sealed containers in the above conditions.

QUALITY ASSURANCE

All products are manufactured in a plant, the quality management system of which is certified/ registered as being in conformity with BS EN ISO 9001, ISO 14001 and OHSAS 18001. Ultra Floor products are guaranteed against defective materials and manufacture and will be replaced or money refunded if the goods do not comply with our promotional literature. However, we cannot accept responsibility arising from the application or use of our products because we have no direct or continuous control over where and how our products are used. All Ultra Floor products are sold subject to our terms and conditions of sale, copies of which may be obtained upon request.

HEALTH & SAFETY

Please ensure that the appropriate PPE is used when preparing, mixing and applying products. Always wash hands before consuming food and make sure that materials are kept safely out of reach of children and animals. Please dispose of packaging and waste appropriately. A full Material Safety Data Sheet relating to this product is available from www.instarmac.co.uk

CORROSIVE, HARMFUL - CONTAINS 2.4,6-TRIS (DIMETHYLAMINOMETHYL) PHENOL, BIS (DIMETHYLAMINOMETHYL) PHENOL

• R22 Harmful if swallowed • R34 Causes burns • S24/25 Avoid contact with skin and eyes • S26 in case of contact with eyes, finse immediately with plenty of water and seek medical advice • S36/37/39 Wear suitable protective clothing, gloves and eyerface protection • S45 in case of accident or if you feel unwell, seek medical advice immediately (show label where possible) • S60 This material and its container must be disposed of as hazardous waste.